

MD-80 SERIES

FLAMMABLE MATERIAL LOCATIONS



SHER AGENT



MD-80 SERIES

EMERGENCY RESCUE ACCESS-1

**1 PASSENGER AND SERVICE
DOORS**

TO OPEN DOOR

MD-80 SERIES

MD-80 SERIES

MD-80 SERIES

FLIGHT DECK CONTROL SWITCH LOCATIONS



2 "APU FIRE" LIGHT

ENGINE SHUTDOWN AND FIRE PROCEDURE:

- A. FUEL CONTROL LEVER(S) FROM "ON" TO "OFF" (DOWN).
- B. IF LIGHT(S) IN HANDLES ARE ILLUMINATED...
- C. PULL HANDLES FULLY OUT.
- D. ROTATE HANDLE CLOCKWISE.
- E. AFTER 10 SECONDS, ROTATE HANDLES COUNTERCLOCKWISE.

APU SHUTDOWN AND FIRE PROCEDURE

- 1. APU "MASTER OFF" SWITCH TO "OFF" (UP).
- 2. IF "APU FIRE" LIGHT IN OVERHEAD PANEL IS ILLUMINATED...FIRE CONT SW TO "OFF & AGENT ARM"
- 3. FIRE AGENT NO 1 SWITCH TO "DISCH" (DOWN).
- 4. AFTER 10 SECONDS FIRE AGENT NO 2 SWITCH TO "DISCH" (DOWN).

A - FUEL CONTROL LEVERS

CRITICAL SWITCH LOCATIONS AND THEIR OPERATION ARE SHOWN WITH THE EXPANDED VIEWS OF THE CONTROL MODULES.



MD-80 SERIES

EXTERNAL APU FIRE CONTROLS

APL